

CAT® FOOTWEAR

B.I.Y.

STONE FIRE PIT

by @the_dirt_ninja



TOOLS LIST:

- ✓ Wheelbarrow
- ✓ Rake
- ✓ Shovel
- ✓ Hand Tamper
- ✓ 2' Level
- ✓ Tape Measure
- ✓ Marking Paint
- ✓ Rubber Mallet

1. CHECK WITH LOCAL TOWN/CITY ORDINANCES ABOUT FIRE PITS AND THE DISTANCE THEY NEED TO BE FROM YOUR HOME

2. HAVE FIRE PIT DELIVERED AND PLACED AS CLOSE TO WORK SITE AS POSSIBLE. HAVE HALF YARD OF $\frac{3}{4}$ " GRAVEL DELIVERED

3. MARK OUT AREA WHERE FIRE PIT WILL GO AND MARK 60" CIRCLE FOR EXCAVATION

4. DIG DOWN APPROXIMATELY 6" FOR FIRE PIT. EXCAVATE OUT ALL GRASS AND TOP SOIL

5. USE WHEELBARROW TO MOVE IN $\frac{3}{4}$ " GRAVEL. LEVEL WITH RAKE AND HAND TAMP IN 2" LIFTS UP TO DESIRED HEIGHT

7. PLACE FIRST FIRE PIT BLOCK AND LEVEL IT. CONTINUE PLACING THE REST OF BLOCKS IN A CIRCLE, LEVELING EACH ONE

8. START TO PLACE SECOND LEVEL OF BLOCKS BY PLACING THE FIRST BLOCK HALF WAY ON 2 BLOCKS TO BREAK UP THE SEAMS. REPEAT THIS STEP UNTIL YOUR FIRE PIT IS AT YOUR DESIRED HEIGHT OR BLOCKS ARE USED

9. INSERT METAL RING (IF PROVIDED)

10. TOUCH UP AROUND FIRE PIT WITH NEW TOPSOIL

11. ENJOY!

